



# SPARE PARTS.

**THUNDER** 380 CC, Concealed Carry Pistol

1. Slide
6. Extractor
7. Extractor spring
8. Extractor pin
9. Firing pin
10. Firing pin spring
11. Manual Safety lever / Decocking
12. Manual Safety spring
13. Manual Safety stop pin
14. Slide catch spring
15. Slide catch
16. Barrel pin
17. Ejector
18. Frame
19. Slide stop
20. Slide stop spring
21. Disassembler lever
22. Trigger spring
23. Trigger
24. Trigger pin
28. Drawbar/ Disconnecter
29. Drawbar/ Disconnecter spring
30. Magazine catch
31. Magazine catch spring
32. Magazine catch pin
33. Hammer
34. Hammer spring guide
35. Hammer spring
36. Sear
37. Sear pin
38. Hammer release cam
39. Hammer pin
40. Hammer release cam bushing
41. Hammer release cam pin
42. Magazine safety
43. Magazine safety spring
44. Magazine tube
45. Magazine follower
46. Magazine spring
47. Magazine butt plate rivet
48. Magazine butt plate
49. Grip screw
50. Barrel
51. Recoil spring
54. Grip (right)
55. Grip (left)
58. Lock stop of the IBS
59. Lock stop spring of the IBS
60. Body lock of the IBS
61. IBS key
62. Automatic safety
63. Automatic safety spring
64. Automatic safety cam
65. Drawbar support  
supplementary washer
66. Drawbar support elastic washer
75. Loaded chamber indicator
76. Transmission pin
77. Indicator pin
78. Indicator spring
79. Insert

**IBS: Integral blocking system**